

SuperSprings Application Sheet-January 2010

Ford	F250 Super Duty (with factory top overloads) - Heavy Loading	08-10	SSA10	NO	3000	
Ford	F250 Super Duty (with factory top overloads) - Extra Heavy Loading Only	08-10	SSA15	NO	5000	
Ford	F350 (no factory top overloads) - Regular Loading	73-99	SSA12	NO	5000	
Ford	F350 (with factory top overloads) - Regular Loading	73-99	SSA12	NO	5000	
Ford	F350 Super Duty (no factory top overloads) - Regular Loading	80-07	SSA16	NO	3000	Square shackle to the front
Ford	F350 Super Duty (no factory top overloads) - Heavy Loading	80-07	SSA13	NO	5000	Square shackle to the front
Ford	F350 Super Duty (with factory top overloads) - Regular Loading	80-07	SSA16	NO	3000	Square shackle to the front
Ford	F350 Super Duty (with factory top overloads) - Extra Heavy Loading Only	80-07	SSA22	NO	5000	
Ford	F350 Super Duty (no factory top overloads) - Regular Loading	08-10	SSA10	NO	3000	Long shackle to front
Ford	F350 Super Duty (no factory top overloads) - Heavy Loading	08-10	SSA15	NO	5000	Long shackle to front
Ford	F350 Super Duty (with factory top overloads) - Regular Loading	08-10	SSA10	NO	3000	Long shackle to front
Ford	F350 Super Duty (with factory top overloads) - Heavy Loading	08-10	SSA15	NO	5000	Long shackle to front
Ford	F250 Super Duty - Chassis Cab (with factory overload) - Heavy Loading	88-06	SSA22	NO	4000	
Ford	F350 Super Duty - Chassis Cab (with factory overload) - Heavy Loading	88-10	SSA22	NO	4000	
Ford	F350 Super Duty - Chassis Cab (with factory overload) - Extra Heavy Loading Only	88-010	SSA25	NO	4000	
Ford	F450 Super Duty Pickup (with factory overload above) - Heavy Loading	08-10	SSA22	NO	5000	
Ford	F450 Super Duty Pickup (with factory overload above) - Heavier Loading	08-10	SSA25	NO	5000+	
Ford	F450 Super Duty Pickup (with factory overload above) - Extra Heavy Loading Only	08-10	SSA17	NO	5000+	
Ford	F450 Super Duty - Chassis Cab (with factory overload) - Heavy Loading	99-10	SSA22	NO	5000	
Ford	F450 Super Duty - Chassis Cab (with factory overload) - Heavier Loading	99-10	SSA25	NO	5000+	
Ford	F450 Super Duty - Chassis Cab (with factory overload) - Extra Heavy Loading Only	99-10	SSA17	NO	5000+	Use SSA17 for extra HD commercial load applications
Ford	F550 Super Duty - Chassis Cab (with factory top overloads)	99-10	SSA17	NO	5000+	
Ford	Ranger - Regular Loading	83-09	SSA5	YES	2000	
Ford	Ranger - Heavy Loading	83-09	SSA8	YES	3000	
Ford	Ranger - Regular Loading	2010	SSA30	NO	2000	
Ford	Ranger - Heavy Loading	2010	SSA31	NO	3000	
Ford	Bronco - Regular Loading	78-96	SSA5	YES	2000	
Ford	Bronco - Heavy Loading	78-96	SSA8	YES	3000	
Ford	Bronco II	84-90	SSA5	YES	2000	
Ford	Explorer	98-01	SSA3	NO	2000	Use upper shackle bolt hole in front
Mercury	Mountaineer	98-01	SSA3	NO	2000	Use upper shackle bolt hole in front
Ford	Sport Trac 2x4, 4x4	98-06	SSA3	NO	2000	Use upper shackle bolt hole in front
Ford	E150	75-07	SSA8	YES	3000	
Ford	E150	08-10	SSA8	NO	3000	
Ford	E250 - Regular Loading	75-07	SSA8	YES	3000	
Ford	E250 - Heavy Loading	75-07	SSA12	YES	4000	
Ford	E250 - Regular Loading	08-10	SSA8	NO	3000	
Ford	E250 - Heavy Loading	08-10	SSA12	NO	4000	
Ford	E350 - Regular Loading	75-07	SSA8	NO	3000	
Ford	E350 - Heavy Loading	75-07	SSA12	NO	4000	
Ford	E350	08-10	SSA12	NO	4000	
Ford	E350 Cutaway Box - Heavy Loading	92-10	SSA12	NO	4000	
Ford	E350 Cutaway Box - Extra Heavy Loading Only	92-10	SSA22	NO	5000	Use SSA22 for extra HD commercial load applications
Ford	E350 Class C RV - Heavy Loading	01-10	SSA13	NO	5000	
Ford	E450 Cutaway Box - Heavy Loading	01-10	SSA22	NO	5000+	
Ford	E450 Cutaway Box - Extra Heavy Loading	01-10	SSA25	NO	5000+	Use SSA25 for extra HD commercial load applications
Ford	E450 Class C RV - Heavy Loading	01-10	SSA22	NO	5000+	
Ford	E450 Class C RV - Extra Heavy Loading	01-10	SSA25	NO	5000+	
Ford	FORD TRANSIT CONNECT	2010	SSA29	NO	3000	
ISUZU, MAZDA, NISSAN, TOYOTA, STERLING						
Isuzu	NPR (for 2008-2009 models remove front spring-clip)	00-10	SSA22	NO	5000+	2008 to 2009 Diesel version - requires mods to PSP1 - check with factory
Isuzu	NPR - HD (for 2008-2009 models remove front spring-clip)	00-10	SSA22	NO	5000+	2008 to 2009 Diesel version - requires mods to PSP1 - check with factory
Isuzu	B Series Pickup - Regular Loading	94-08	SSA5	YES	2000	
Mazda	B Series Pickup - Heavy Loading	94-08	SSA8	YES	3000	
Mazda	Pickup	86-97	SSA2	NO	1800	
Nissan	Frontier 2x4 - Regular Loading	98-04	SSA2	NO	1800	
Nissan	Frontier 2x4 - Heavy Loading	98-04	SSA7	NO	3000	
Nissan	Frontier 4x4 - Regular Loading	98-04	SSA2	YES	2000	
Nissan	Frontier 4x4 - Heavy Loading	98-04	SSA7	YES	3000	
Nissan	Frontier 2x4,4x4	05-10	SSA1	YES	2000	Square shackle upper bolt hole rear / Trim bumpstop
Nissan	Xterra	00-07	SSA1	NO	2000	
Nissan	Titan	04-10	SSA20	NO	3000	Includes special mounting kit
Nissan	UD LCF 1200,1300,1400,1800 Series	00-10	SSA22	NO	5000+	
Nissan	Pickup 2x4	80-94	SSA1	NO	1800	
Toyota	Pickup 4x4	80-94	SSA1	YES	1800	
Toyota	Tacoma 2x4 - Regular Loading	95-00	SSA2	NO	1800	
Toyota	Tacoma 2x4 - Heavy Loading	95-00	SSA7	NO	3000	
Toyota	Tacoma 2x4	01-10	SSA1	NO	1800	Square shackle to Rear use upper bolt hole
Toyota	Tacoma 4x4	95-04	SSA18	NO	3000	MTKT included. Remove bumpstop. / Short shackle to the rear
Toyota	Tacoma Prerunner	95-04	SSA18	NO	3000	MTKT included. Remove bumpstop. / Short shackle to the rear

SuperSprings Application Sheet-January 2010

Toyota	Tacoma 4x4	05-10	SSA19	NO	3000	MTKT included. Remove bumpstop. / Square shackle to rear. Use upper bolt hole /thread roller bolts to outside
Toyota	Tacoma 2x4 Prerunner	05-10	SSA19	NO	3000	MTKT included. Remove bumpstop. / Square shackle to rear. Use upper bolt hole /thread roller bolts to outside
Toyota	Tundra	98-06	SSA8	YES	3000	Trim bumpstop 1"
Toyota	Tundra - Regular Loading	07-10	SSA4	NO	3000	Mounting kit & special bumpstop included with this dedicated spring
Toyota	T100 2x4 - Regular Loading	93-98	SSA2	NO	2000	
Toyota	T100 2x4 - Heavy Loading	93-98	SSA7	NO	3000	
Toyota	T100 2x4 - Extra Heavy Loading	93-98	SSA11	NO	3000	
Toyota	T100 4x4 - Regular Loading	93-98	SSA2	YES	2000	Use SSA2 for regular load applications
Toyota	T100 4x4 - Heavy Loading	93-98	SSA7	YES	3000	Use SSA7 for heavier load applications
Toyota	T100 4x4 - Extra Heavy Loading	93-98	SSA11	YES	3000	Use SSA11 for heavier load applications
Sterling	Sterling Bullet 4500 HD- Regular Loading	07-09	SSA23	NO	4000+	
Sterling	Sterling Bullet 4500 HD- Heavy Loading	07-09	SSA24	NO	5000+	
Sterling	Sterling Bullet 5500 HD - Regular Loading	07-09	SSA23	NO	4000+	
Sterling	Sterling Bullet 5500 HD - Heavy Loading	07-09	SSA24	NO	5000+	
Sterling	Sterling Bullet 5500 HD - Extra Heavy Loading	07-09	SSA17	NO	5000+	
Sterling	Sterling Bullet 360 LCF	08-09	SSA22	NO	5000+	