

PART NUMBER
SSC-52



SCAN HERE: To watch a video of this installation



BEFORE YOU BEGIN

**PRIMARY APPLICATIONS
REAR SUSPENSION FOR:**

- > RAM 2500 4 X 2
(2014 - present)
- > RAM 2500 4 X 4
(2014 - present)

PARTS LIST


Item	Part #	Description	QTY
A	202052	SSC-52 Coil Spring	2

TOOLS REQUIRED

- > Floor Jack
- > Jack Stands
- > Wheel Chocks
- > 8mm Socket/wrench
- > 16mm Socket/wrench
- > 17mm Socket/wrench
- > 18mm Socket/wrench
- > 21mm Socket/wrench
- > Torque wrench

NOTE:

Pay attention to how the factory spring is oriented when removed and install the SuperCoil in the same orientation.



Questions or Concerns?

Scan here:



or visit:
superspringsinternational.com

SAFETY NOTICE: We recommend installation be done by a professional or persons with sound mechanical knowledge.

WARNING: These instructions are a general guide for installation. SuperSprings International (SSI) assumes no liability for the actual installation process. Consumers and installers should apply common automotive safety practices when raising and working on any vehicle. **Do not put yourself in a position where, if the vehicle were to move unexpectedly, you may be injured.** SSI's products are designed to improve vehicle ride quality. Do not load any vehicle beyond the manufacturer's specifications.

Never exceed the manufacturer's Gross Vehicle Rating (GVWR) located on your vehicles identification tag.

BEFORE INSTALLATION: Ensure the vehicle is on a hard level surface, the parking brake is ON, with the ignition OFF, and place chocks in front of and behind the tires to prevent the vehicle from moving.

DURING AND/OR AFTER INSTALLATION: Ensure emergency brake cables are not touching the SSI products. Secure any cables out of the way with zip ties or by re-routing. Ensure all A/C lines, brake cables, and frame are clear of contact or interference.

PART NUMBER
SSC-52



IMPORTANT NOTICE: We recommend installation be done by a professional or persons with sound mechanical knowledge.

INSTALLATION

1. Park the vehicle on a hard, level surface and engage the emergency brake. Place chocks in front and behind wheels to prevent rolling. Observe all safety precautions and wear safety glasses.
 2. Raise the rear of the vehicle by the axle using a jack rated for the vehicle weight and support the frame with jack stands. Keep the jack in place supporting the weight of the axle.
 3. Remove the rear wheels.
 4. Unbolt the rear sway bar end links from the chassis.
 5. Unbolt the track bar from the axle.
 6. With the axle still supported, unbolt the shocks from the axle.
 7. Carefully lower the axle just enough to remove the factory coil springs and be careful to avoid putting stress on the ABS and brake lines.
- NOTE:** Pay attention to how the factory spring is oriented when removed and install the SuperCoil in the same orientation.
8. Remove the factory coil isolators from the factory coils and place them on the SuperCoils.
 9. Install the SuperCoils and raise the axle enough to connect the shocks to the axle. Torque the shock bolts to factory specifications.

10. Reconnect the track bar to the axle and torque the bolt to factory specifications.
11. Reconnect the sway bar links to the chassis and torque the bolts to factory specifications.
12. Install the wheels and torque the lug nuts to factory specifications.
13. Raise the vehicle and remove the jack stands. Carefully lower vehicle to the ground.
14. Remove the wheel chocks from in front and behind the front wheels.
15. Register the warranty for your SuperSprings International part. A warranty card can be found in the box your part came in.

Part Number: SSC-52

Product Line: SUPERCOILS REAR

Page 2

Questions or Concerns?

Scan here:



or visit:
superspringsinternational.com

SAFETY NOTICE: We recommend installation be done by a professional or persons with sound mechanical knowledge.

WARNING: These instructions are a general guide for installation. SuperSprings International (SSI) assumes no liability for the actual installation process. Consumers and installers should apply common automotive safety practices when raising and working on any vehicle. **Do not put yourself in a position where, if the vehicle were to move unexpectedly, you may be injured.** SSI's products are designed to improve vehicle ride quality. Do not load any vehicle beyond the manufacturer's specifications.

Never exceed the manufacturer's Gross Vehicle Rating (GVWR) located on your vehicles identification tag.

BEFORE INSTALLATION: Ensure the vehicle is on a hard level surface, the parking brake is ON, with the ignition OFF, and place chocks in front of and behind the tires to prevent the vehicle from moving.

DURING AND/OR AFTER INSTALLATION: Ensure emergency brake cables are not touching the SSI products. Secure any cables out of the way with zip ties or by re-routing. Ensure all A/C lines, brake cables, and frame are clear of contact or interference.

REV. 2.03 | AUG 2023